



**DUROVIN**  
BATHROOMS

# Stone Shower Tray Installation Manual

**Customer Notification**

Please be advised these instructions are for the Shower tray only. When purchasing the shower tray only the tray can be fitted before or after tiling and sealed to create a watertight edge. Should this item be purchased as part of any of our Shower enclosures the tiling must have taken place before tray installation and sealed with waterproof membrane and/or sealant. This is to prevent the tile width causing the panels to overhang the tray.

