



IMPORTANT SAFETY NOTES

- •Under no circumstances should you attempt to drill through the glass, damage or injury may occur
- •Please handle all glass with care, avoiding knocks and shock loading to all sides and edges. Safety glass cannot be reworked.
- •Care should be taken when drilling into walls to avoid hidden pipes or electrical cables.



BR7003 Wet Room Instructions

Tools Required



Two people required. We recommend that a technically competent installer should undertake this installation.

Be sure you have all included parts and tools required before beginning installation and that you have plenty of space for assembly.


PRE-INSTALLATION AND TECHNICAL REQUIREMENTS

- All dimensions are shown in millimetres, except where otherwise indicated.
- Ensure that the enclosure set is fitted to a level floor and vertical wall surface.
- This instruction manual is applicable for both pre-tiled wall and plain walls.
- The wall fixings included with this product are suitable for solid walls only. Plasterboard or stud walls may require specialist fixings (not supplied).
- Due to the possibility of residual spray, the area around the outside of the shower tray should be tiled, or made otherwise water resistant.

IMPORTANT SAFETY NOTES

- Under no circumstances should you attempt to drill through the glass, damage or injury may occur
- Please handle all glass with care, avoiding knocks and shock loading to all sides and edges. Safety glass cannot be reworked.
- Care should be taken when drilling into walls to avoid hidden pipes or electrical cables.


Included Parts




Ref	Description	Illustrations	Qty	Ref	Description	Illustration	Qty
1	Glass Panel		1	6	End Cap		1
2	Aluminium Profile		1	7	End Cap		1
3	Decorative Caps		3	8	ST4X12 Screws		3
4	Wall Plugs		4	9	Supporting Bar		1
(5)	ST4X40 Screws		4				

Aluminium profile assembly


1. Measure how far the glass panel will be from the wall.



- 2. Check with a spirit level that the aluminium profile is level with the wall.
- 3. Mark with a pencil where holes will be drilled.




- 4. Drill holes and insert wall plugs.
- 5. Screw the aluminium profile onto the wall.




Glass penal assembly

- 6. Insert the glass panel into the aluminium profile.


 Note: be cautious when lifting glass to avoid damage or injury.
- 7. Drill hole for the supporting bar, inserting wall plug.
- 8. Remove the end of supporting bar, screwing it onto the wall.
- 9. Drill through profiles being sure to avoid the glass, screwing aluminium profile onto profile of glass panel.





Supporting bar assembly

- 11. Insert the supporting bar, tightening screws.
- 12. Slide the opposite end of supporting bar onto glass panel, tightening screw.
- 13. Insert end caps into the top of the aluminium profile.



Apply silicone sealant

14. Silicone around the aluminium profile and glass panel, allowing 24 hours for it to dry.

